

Foundation

Art.: 05.0100.9999

Plastic bag 10 pieces

Foundation is part of the Innotec Velours Repair System and the Innotec Velours Repair System - VW (VAS 6221). It reinforces textiles to help build up upholstery repairs.



Base:	Mixture of polyester, viscose and acryl
Density:	± 50 g/m ²
Dimensions:	15 cm x 15 cm
Application conditions:	+15°C to +30°C (Innotec Base Glue)
Type of surface:	Almost all modern upholstery systems
Surface preparation:	The surface must be clean, dry and free of grease. Clean upholstery with Innotec Remover and leave to evaporate for 2 minutes.
Application method:	Cut out a circle of Foundation that is approximately 5 mm greater in circumference than the hole. Make an incision between the filling and the cloth around the damage. Bring the Foundation in the incision between cloth and filling by using the included Spatula . Put the tube opening of the Innotec Base Glue between the cloth and the Foundation and apply a small amount of Innotec Base Glue around the repair area to glue the Foundation. Put the repair under light pressure and let it dry for 5 minutes. Finish the repair with Innotec Base Glue and Innotec Fibres . See also the directions for use of the Innotec Velours Repair System .
Cleaning of materials used:	With Innotec Remover
Cleaning of hands:	With Innotec Safe Hand Clean Plus and water
Shelf life:	Unlimited in original, unopened packaging
Storage conditions:	No restriction
EAN Code:	5400563025697

This technical info sheet replaces all previous versions.

All information is supplied without obligation and based on our knowledge and experience with the product under normal conditions. In practice, the information supplied can in no way replace the tests that need to be performed before first use of the product. Only prior testing of the product can prove whether the product is indeed suitable for the intended application (or not). Thus, we cannot accept any responsibility in case our products are not used in compliance with the advices given.

If the product should not meet the quality requirements, we will only reimburse up to a maximum of the purchase price of the product. We accept no responsibility whatsoever and shall under no circumstances be liable for damage or consequential loss arising from the use of the product.





For information concerning safe use and storage, please refer to the safety data sheet of the product concerned.

